



**DM Series Firmware Upgrade Procedure**

*Date:*02/18/2013

*Solution:* To upgrade the DM series of DMM's, follow these steps:

1. Download the proper firmware file and transfer to the root directory of a USB memory stick. Valid firmware for the DM series have the \*.LDR file extension.
2. Plug the instrument in to an uninterruptible power supply and turn the instrument on.
3. Insert USB memory stick into front panel USB connection.
4. The instrument should recognize the new firmware and ask you if you would like to continue with the upgrade.



5. Press Done to start the firmware upgrade



6. The instrument will begin the upgrade and will show a progress bar.



**WARNING!** Don't power cycle or disturb the instrument until the upgrade is complete.. as the instrument can be damaged.

7. Power cycle the instrument to complete the upgrade procedure.



### **Headquarters**

RIGOL TECHNOLOGIES, INC.

No.156,Cai He Village,

Sha He Town,

Chang Ping District, Beijing,

102206 P.R.China

Tel:+86-10-80706688

Fax:+86-10-80705070

Email: [support@rigol.com](mailto:support@rigol.com)

### **USA**

RIGOL TECHNOLOGIES,USA INC.

7401 First Place, Suite N

Oakwood Village

OH 44164, USA

Toll free: 877-4-RIGOL-1

Office: (440) 232-4488

Fax: (216)-754-8107

Email: [info@rigol.com](mailto:info@rigol.com)

### **EUROPE**

RIGOL TECHNOLOGIES GmbH

Lindbergh str. 4

82178 Puchheim

Germany

Tel: 0049- 89/89418950

Email: [info-europe@rigoltech.com](mailto:info-europe@rigoltech.com)