



Uncompromised Products...  
Unprecedented Value

## How to Update the M300 Firmware

*Date:* 10/11/2014

*Solution:*

To update the M300 firmware, please follow these instructions:

1. Download the proper firmware file and transfer to the root directory of a USB memory stick.
  - Valid firmware for the M300 series have the \*.*UPD* file extension.
  - A USB stick with no folders or files is recommended
2. Plug the instrument in to an uninterruptible power supply and turn the instrument on.
3. Copy the M300 update file to the root directory of a USB memory stick
4. Power on the M300 and insert the USB memory stick into the front panel USB port.
5. Press **UTILITY** and you should see the **UPDATE** menu become active. This is indicated by the letters changing from grey to white as shown below



Figure 1: M300 Utility menu showing active UPDATE item present when a valid M300 firmware update file (\*.UPD) is available on a USB memory stick on the front panel.

- 6. Press the blue-grey key under the UPDATE menu item
- 7. Select the M300 UPD file you would like to use and press the blue-grey key under COMMIT





8. The instrument will then ask you to confirm the update. Press OK.
9. After a few minutes, the instrument may ask you to restart. Press OK.
10. You can check the firmware information by pressing UTILITY > INFO



## Headquarters

RIGOL TECHNOLOGIES, INC.  
No.156,Cai He Village,  
Sha He Town,  
Chang Ping District, Beijing,  
102206 P.R.China  
Tel:+86-10-80706688  
Fax:+86-10-80705070  
Email: [support@rigol.com](mailto:support@rigol.com)

## USA

RIGOL TECHNOLOGIES,USA INC.  
7401 First Place, Suite N  
Oakwood Village  
OH 44164, USA  
Toll free: 877-4-RIGOL-1  
Office: (440) 232-4488  
Fax: (216)-754-8107  
Email: [info@rigol.com](mailto:info@rigol.com)

## EUROPE

RIGOL TECHNOLOGIES GmbH  
Lindbergh str. 4  
82178 Puchheim  
Germany  
Tel: 0049- 89/89418950  
Email: [info-europe@rigoltech.com](mailto:info-europe@rigoltech.com)