



### How to enable the Frequency Hopping option on the DG5000 series

Date:09/12/2011

*Solution:* The Rigol DG5000 series of arbitrary waveform generators have optional Frequency Hopping capabilities. Here are the steps to obtaining and activating the option.

- 1) Contact your local Rigol Sales office to obtain a copy of the Frequency Hopping license for your instrument.

NOTE: Each license is tied to an individual serial number, so please have your serial number ready when you are purchasing the license.

- 2) In most cases, the license will be emailed to you. The license file for the Frequency Hopping option will have a *.CEN* file extension.
- 3) Save the *.CEN* file to the root directory of a USB memory stick.
- 4) Insert the USB stick into the front panel of the DG5.
- 5) Press the Save/Recall button.
- 6) Press Browser button until DIR is shown.

NOTE: DIR stands for Directory and will allow you to browse different folders and directories. The FILE option will allow you to select specific files.

- 7) Rotate the selection knob to select the D: drive. This is the standard drive letter for the USB memory stick.
- 8) Press File Type and select ALL FILES.



- 9) Press Browser button until FILE is indicated.
- 10) Rotate the selector knob in the file explorer window and select the *.CEN* file.
- 11) Press Read button.